












KEGE rond trimless - 4760 / 4761



1. fix the pin
in the hole



2. switch the
second pin in
the slot



3. fix the screw, to
secure the luminaire
and adjust the gimble
strength