

Diffuser Removal

1

Opal Snap-in

Lift and tilt

LED Tray Removal

2a

Remove the corresponding LED tray from over the bracket mounting to allow access

LED Tape Removal

2b

Unclip the FIRO profile from the white plastic mounting clips — *NB # don't hang the profile from the wires.*

Mounting The Support Bracket

3

Screw the support in the desired space on the wall, using countersink screws.

Profile Bolt

4

Slide the support bolt into the profile's closest suspension channel to the wall.

Mounting The Profile

5

Lift the profile into position, fastening the nut onto the profile bolt.

Wiring

6

Ensure all terminations are complete and secure.  
Please use document  
\*Optelma Wiring Instructions – REV V\*


Reassembly Of Luminaire

7

Reassembly is the reverse of the previous stages 1 and 2.

Additional Fixings - End Cap

Two countersunk screws hold each endcap to the profile



Additional Fixings – Flush Connector

Four screws in each profile to grip the flush connector, do not overtighten.

