



Mounting Brackets

Clip the 2 metal brackets into the Keno frame




Profile adjustment

Adjust the height of the profile with the adjustment bolt.



Spotlight installation

Locate the pins on the spotlight into the slots, and twist to secure.



Wiring

Ensure all terminations are complete and secure according to the wiring instructions included with your remote driver.