

Diffuser Removal

Opal Snap-in

Lift and tilt

1

LED Tray Removal

2a

Remove the corresponding LED tray from over the bracket mounting to allow access

LED Tape Removal

2b

Unclip the FIRO profile from the white plastic mounting clips — *NB # don't hang the profile from the wires.*

Mounting The Boss

3

Screw the boss to the ceiling and slide the suspension wire into the mating boss, screw into the ceiling boss.

Profile Brackets

4

Screw the splitter cable into the clutch using grub screw, and slide into the profile.

Mounting The Profile

5

Push the wire through the clutch and adjust to height, snip off any excess

Wiring

6

Ensure all terminations are complete and secure.

Please use document

Optelma Wiring Instructions – REV V


Reassembly Of Luminaire

7

Reassembly is the reverse of the previous stages 1 and 2.


Additional Fixings - End Cap

Two countersunk screws hold each endcap to the profile

A technical line drawing showing a cross-section of a lighting profile. An end cap is being aligned with the profile. Two screws are shown passing through the end cap into the profile, indicated by dashed lines and arrows. An arrow points to the end cap.

Additional Fixings – Flush Connector

Four screws in each profile to grip the flush connector, do not overtighten.

A technical line drawing showing a flush connector being attached to a lighting profile. The connector is a rectangular plate with four screws on each side. Arrows labeled '1' and '2' indicate the screw locations. An arrow points to the 'Next profile'.